

**FUN:BIKES**

**LET THE FUN BEGIN**

## **Changing the Motor in a Chaos Scooter**

This is a simple guide, intended for Funbikes Customers who have purchased a Chaos Scooter, It contains instructional steps on how to change the motor, and includes images to aid you in the process.



# Changing the Motor in a Chaos Scooter

This guide explains how to change the motor.

## What product does this guide apply to?

- Chaos 48 Volt 1000w Electric Scooter Powerboard
- Chaos 48 Volt 1000w Electric Scooter Big Wheel Powerboard
- Chaos Sport 48 Volt 1600w Electric Scooter Big Wheel Powerboard
- Chaos Sport 48 Volt 1600w Electric Scooter Big Wheel Off Road Powerboard



## Step 1

---

Remove your seat post and lift your deck [I would advise securing your deck so it doesn't come down on your head].



## Step 2

---

Disconnect the battery pack and remove the battery pack.



## Step 3

---


Remove plate to allow access to the control box (not applicable on all models).



## Step 4

---


Locate the wires from your motor.



## Step 5


---

Disconnect the motor wires. You will need to carefully remove the mastic from the connector then use a small screwdriver or pick to push the pins out.



# Step 5 Continued

---



## Step 6

---

Feed the cable back down the chassis.

## Step 7

---

Loosen your rear wheel.



## Step 8

---

Slacken off your chain tensioners.



## Step 9

---

Remove your chain.

## Step 10

---

Remove one of your shock bolts on the left-hand side.



## Step 11

---


Move the shock out of the way.



## Step 12

---

Remove the two allen key bolts holding the motor in place.



## Step 14

---

Remove the motor.

***Now reverse this procedure when fitting the new motor.***



# **FUN:BIKES**

**WWW.FUNBIKES.CO.UK**

**Follow FunBikes  
for Updates**



**If you require more assistance, please feel  
free to contact us:**

**Telephone- 01664 498 6142**

**Email- tech@funbikes.co.uk**

